



BETTER TOOLS



Pop 'n Trot Plastic Strap Knife

Strap Knife Features

Five inch contoured handle

Dual straight blades for regular use

Integrated ring blade for Pop 'n Trot operation

Guarded blades prevent injuries


Glass-impregnated plastic construction for lightweight durability.

Bright yellow color for recognizability

Molded belt strap prevents loss

Quick, easy, safe replacement of dull blades; requires only a screwdriver.

Specifically engineered for cutting plastic straps; not for use on plastic wrap or cardboard.



For additional info or to purchase knives and replacement blades, contact Better Tools by phone at 800-798-6657, online at www.better-tools.com or request product information by email at info@better-tools.com



Safe operation with ring blade in use for Pop 'n Trot utilization.



Safe operation with straight blades in use for general strap cutting.

Procedures for safely replacing interchangeable blades.



Using a Phillips screwdriver, remove the three screws that hold the purple blade guard in place. Be careful not to lose the retaining nuts on the back of the knife that hold these screws in place.



Remove and set aside the purple blade guard and retaining screws.. Carefully lift out the dull blades and discard in the approved manner.



Unwrap new blades and fit them to the handle. You must replace the blades in the same order indicated above, making sure that the bevels on the blades face away from each other. Replace purple blade guard and tighten retaining screws.